

Sequence data search and fetching metadata

Date etc

NC STATE UNIVERSITY



Infectious disease dynamics lab

- Learning to identify and download genomic data from NCBI.
 - Understand the differences between SRA, SRX, PRJ, SAM and SRR.
 - Identify the different IDs in NCBI website.

Gene sequencing



The Mendelian gene is a basic unit of heredity.

The molecular gene is a sequence of nucleotides in DNA, that is transcribed to produce a functional RNA and protein.


Gene detection in humans: Disease detection (i.e. cancer)

Gene detection in other animals: Disease detection, breeding.

Gene detection in pathogens → AMR, virulence, other specific genes




DNA can be cut in small pieces and sequenced based on a **reference genome**.




- **Library preparation:** Long strands of DNA are cut in small fragments, and specific sequences of DNA called **adapters** are added at each end of each fragment, including an **index** to identify the sample.
- **Sequencing by synthesis (Illumina):** A glass surface called flow cell contains small fragments of DNA called **oligonucleotides**. These match the adapters in the library.

DNA can be cut in small pieces and sequenced based on a **reference genome**.




- One of your sequences (forward sense) attaches to one of the oligos by the adapter and it gets copied. This copy is the continuation of the oligo but it is the opposite sense (reverse). The forward sequences remaining are washed away.
- **Clonal amplification via PCR:** The reverse sequence bends and attaches to the next oligo, and it is copied. The result is the original sense of the sequence (forward sense). The reverse sense sequences are discarded.

DNA can be cut in small pieces and sequenced based on a **reference genome**.




- One of your sequences (forward sense) attaches to one of the oligos by the adapter and it gets copied. This copy is the continuation of the oligo but it is the opposite sense (reverse). The forward sequences remaining are washed away.
- **Clonal amplification via PCR:** The reverse sequence bends and attaches to the next oligo, and it is copied. The result is the original sense of the sequence (forward sense). The reverse sense sequences are discarded.

DNA can be cut in small pieces and sequenced based on a **reference genome**.




- One of your sequences (forward sense) attaches to one of the oligos by the adapter and it gets copied. This copy is the continuation of the oligo but it is the opposite sense (reverse). The forward sequences remaining are washed away.
- **Clonal amplification via PCR:** The reverse sequence bends and attaches to the next oligo, and it is copied. The result is the original sense of the sequence (forward sense). The reverse sense sequences are discarded.

DNA can be cut in small pieces and sequenced based on a **reference genome**.




- Sequencing primers bind to the forward strand. In the sequencing medium, there are fluorescent nucleotides with one specific fluorescent tag, polymerase enzymes and a terminator.
- Only one nucleotide per cycle is attached to the sequence, and its color is detected and stored by the instrument. Finally, the index gets sequenced. **This is called single-end.**
- If a second index is sequenced, along with the reverse strand of the library, it is known as **paired-end sequencing**.

DNA can be cut in small pieces and sequenced based on a **reference genome**.




AGTCCCTGAATCGA




- After several filters within the instrument, the resulting sequences are **demultiplexed**, which means sort reads by sample based on the attached indexes.
- After demultiplexing, the sequences are **mapped to a reference genome**.
- This type of sequencing is **short read sequencing**, with fragments between 75-300bp

Long-read sequencing. Oxford Nanopore Technologies (ONT)



- Similar than with Illumina, libraries are prepared where an adapter is attached to each sequence.
- ONT sequencer flow cells are made of an electric-resistant bilayer created by a synthetic polymer with an array of nanopores ($\sim 1.8\text{nm}$).
- A potential is applied across the membrane, resulting in a current flowing only through the nanopores.

Long-read sequencing. Oxford Nanopore Technologies (ONT)



- Single molecules flowing through the nanopores cause characteristic disruptions in the electric current across the membrane.
- Measuring those disruptions, the molecules can be easily identified.
- ONT analyzes intact DNA strands that pass through the nanopores and analyzed in real time.
- By preparing the DNA to have a hairpin structure, ONT can produce pair-end data in one continuous read.
- Long-read sequencing still has higher error rate than short-read sequencing.


FASTQ File Format Analysis





National Library of Medicine
National Center for Biotechnology Information





NIH National Library of Medicine
National Center for Biotechnology Information

All Databases ▼ Search

NCBI Home
Resource List (A-Z)
All Resources
Chemicals & Bioassays
Data & Software
DNA & RNA
Domains & Structures
Genes & Expression
Genetics & Medicine
Genomes & Maps
Homology
Literature
Proteins
Sequence Analysis
Taxonomy
Training & Tutorials
Variation

Welcome to NCBI

The National Center for Biotechnology Information advances science and health by providing access to biomedical and genomic information.

[About the NCBI](#) | [Mission](#) | [Organization](#) | [NCBI News & Blog](#)

Submit

Deposit data or manuscripts into NCBI databases

Download

Transfer NCBI data to your computer

Learn

Find help documents, attend a class or watch a tutorial

Develop

Use NCBI APIs and code libraries to build applications

Analyze

Identify an NCBI tool for your data analysis task

Research

Explore NCBI research and collaborative projects

Popular Resources

- PubMed
- Bookshelf
- PubMed Central
- BLAST
- Nucleotide
- Genome
- SNP
- Gene
- Protein
- PubChem

NCBI News & Blog

Enhancements to ClinVar Website Now Live 31 Jan 2024

As previously announced, we updated the ClinVar website as part of our effort to



HomoloGene Now Redirects to NCBI Datasets Gene 30 Jan 2024

A new way to view and download related genes. *As previously announced*

BLAST FASTA Files Will No Longer Be Available on the FTP Site Effective April 2024 25 Jan 2024

Facilitate nanoscale RI & ST FASTA files

[More...](#)



Sequence Read Archive (**SRA**) data, available through multiple cloud providers and NCBI servers, is the largest publicly available repository of high throughput sequencing data.

Entrez is a molecular biology database system that provides integrated access to nucleotide and protein sequence data, gene-centered and genomic mapping information, 3D structure data, PubMed MEDLINE, and more.

Entrez covers over 20 databases including the complete protein sequence data from PIR-International, PRF, Swiss-Prot, and PDB and nucleotide sequence data from GenBank that includes information from EMBL and DDBJ.



Entrez Molecular Sequence Database System

[PubMed](#)[Entrez](#)[BLAST](#)[OMIM](#)[Taxonomy](#)[Structure](#)

Sequence Read Archive (SRA): repository that stores raw sequencing data. It includes the actual sequences obtained from the high-throughput sequencing machines before any processing or analysis.

PRJ: Refers to a genomic **project**. It represents a collection of related experiments and data associated with a particular scientific investigation.

SRX: Refers to a **sequencing experiment**. It is an organized set of runs, which are the actual sequencing data generated for a sample or set of samples. SRX[...], ERX[...], DRX[...].

SAM: Represents an individual **biological sample** that is part of a project. It is a specific instance of genetic material taken from an organism.

SRR: Represents a **specific run** of sequencing data. It is the raw data generated in a single sequencing run for a particular sample.

SRA

SRA

SRA

Advanced

Full ▾

Send to: ▾

SRX

[SRX23044891](#): SSUIS-Pig-SD57007PPY30516

1 ILLUMINA (Illumina MiSeq) run: 724,708 spots, 362M bases, 194.1Mb downloads

Design: Illumina Nextera XT2

Submitted by: USDA Animal Plant Health Inspection Service-National Veterinary Services Laboratories - DBPL (USDA-NVSL-DBPL)

Study: Streptococcus suis Genome sequencing and assembly

[PRJNA805195](#) • [SRP477340](#) • [All experiments](#) • [All runs](#)[show Abstract](#)

Sample: clinical isolate

[SAMN39082781](#) • [SRS20005910](#) • [All experiments](#) • [All runs](#)Organism: [Streptococcus suis](#)

Library:

Name: SSUIS-Pig-SD57007PPY30516

Instrument: Illumina MiSeq

Strategy: WGS

Source: GENOMIC

Selection: RANDOM

Layout: PAIRED

Runs: 1 run, 724,708 spots, 362M bases, 194.1Mb

SRR

[SRR27368317](#)


724,708

362M

194.1Mb

2023-12-27


ID: 31124544

**SRA**

(Sequence Read Archive → Library)

PRJ 1

(Project → Shelf)

**PRJ 2****PRJ 3****SRX**


(Experiment → book)

SAM

(Sample → Chapter)

SRR

(Run → Paragraph)

SRR 1**SAM 1****SAM 2****SRR 2**

**SRA**

(Sequence Read Archive → Library)

PRJ 1

(Project → Shelf)

**PRJ 2****PRJ 3****SRX**

(Experiment → book)

**SAM**

(Sample → Chapter)

SAM 1**SAM 2****SRR**

(Run → Paragraph)

SRR 1**SRR 2**

Multiple experiments
(SRX) using the
same sample (SAM)

- Sequence details are important (i.e. single vs paired).
- Difference between long and short-read sequencing.
 - FASTq files contain important information.
- Numerous public databases for genomic data.
 - SRA → PRJ → SRX → SAM → SRR.

Questions

